

FORK LIGHT BARRIERS

WITH IO-LINK



FORK LIGHT BARRIERS

WITH IO-LINK

MORE FLEXIBLE, FASTER, MORE PRECISE, SIMPLER AND **EVEN MORE RUGGED - WITH THE EXACT SAME SIZE.**

For decades, di-soric has been developing fork light barriers that set new standards. We are now offering the fork light barrier 4.0 with an innovative dual operation concept, either over IO-Link with the configuration of all sensor functions including 4 selectable sensor modes or through easy manual switching point adjustment with a potentiometer.



IO-Link

Selection of the sensor mode or teach-in over IO-Link




applications

THE EVOLUTION:

FORK LIGHT BARRIERS 4.0

APPLICATION-SPECIFIC CONFIGURATION INSTEAD OF SPECIFIC HARDWARE.

Instead of keeping various forks on hand for different applications, you can save the application-specific configuration, load it into the fork as needed or select the necessary operation mode and get started right away. Device swapping works just as easily.





OGU - OUR MEDIUM FORMAT.

STANDARD IN THE FINEST GRADATIONS.

HIGH RESOLUTION COMBINED WITH AMAZING SPEED AND PRECISION - WITH RED AND INFRARED LEDS - WITHOUT LASERS.

Fork light barriers are the preferred choice wherever small objects or object positions must be detected quickly, precisely and independently of their surface. High switching frequency and maximum resolution means that our medium formats are capable of reliably detecting rapid motion sequences, even of very small parts with diameters starting from 0.2 mm.

The outstanding reproducibility standard of 0.02 mm enables the extremely precise position recognition of objects.

The OGU fork light barriers, available as red-light or infrared-light variants, achieve virtually the same level of performance as laser light barriers in terms of resolution and reproducibility.







FORK OPENINGS IN INCREMENTS OF 10 MM:

30 . 40 . 50 . 60 . 70 . 80 . 90 . 100 MM


WE HAVE EXACTLY THE FORK YOU NEED IF YOU WANT TO ACHIEVE MAXIMUM PERFORMANCE WITHIN A MINIMAL INSTALLATION SPACE.

In contemporary mechanical engineering, design is playing an ever greater role – our slim OGU fork light barriers in the medium format are available in increments of 10 mm and are suitable for the most diverse machine designs. Thus, you can always find the optimally matching fork light barrier for your planned design.

Accumulation monitoring

OGU 081 G3-T3

With the "Power" sensor mode, cleaning cycles are reduced to a minimum through increased transmission power and thus increased functional reserve.





Trigger for high-speed labelers

OGU 081 G3-T3

With the "Speed" sensor mode, it is possible to increase the throughput speed to a maximum at a switching frequency of 8,000 Hz — with consistent precision and reproducibility.

OGU - OUR SMALL ONES: 5, 10 AND 20 MM. SUPER-FAST ON THE SHORT DISTANCE

SO SMALL AND YET SO TOUGH - SPEED UP YOUR MACHINES.

The OGU 005 and 010 are not only our smallest fork light barriers but also our fastest: With a switching frequency of up to 14,000 Hz, they are among the fastest forked light barriers worldwide. Install our fork light barriers, even without the potentiometer being accessible, and simply configure using IO-Link – a greater amount of space cannot be conserved.



High-speed metering application

OGU 010 G3-T3

With the "Speed" sensor mode and a switching frequency of 14,000 Hz, it is possible to measure the speed of small plastic gears on a test bench.



Position monitoring in the device

OGU 021 G3-T3

Configuration using IO-Link and the compact design make it possible to integrate two fork light barriers in the assembly device








OGU - OUR LARGE SIZES.

IS IT ALRIGHT IF IT'S A BIT OVER?

HERE YOU GO! - WHERE OTHERS HAVE GIVEN UP LONG AGO, WE WILL EVEN ADD A BIT: 120 . 170 . 220 . 250 MM

The perfect alignment of transmitter and receiver in our large fork light barriers is assured – as is the visible red light, which further eases the setup of your application. However, the fact that even at such fork openings, small parts in the millimeter range are precisely identified with a reproducibility down to 0.03 mm, makes them excellent.





Position monitoring of the groove in the circular piece

OGU 251 G3-T3

Large fork light barriers with red light LED enable fast commissioning. Glossy objects can be monitored with high precision






OGU STAINLESS STEEL.

PRACTICALLY INDESTRUCTIBLE.


FOR INDUSTRIAL ENVIRONMENTS REQUIRING EXCEPTIONAL FLEXIBILITY AND HIGH PROCESS RELIABILITY.

The OGU Stainless Steel sensors are especially well-suited to applications in packaging technology, the pharmaceutical industry, cosmetics industry and product feeding. Frequent batch changes and modifications to critical production parameters can be implemented easily and quickly using the IO-Link configuration. Available fork openings: 10, 30, 50, 80, and 120 mm.

Additional benefits of the OGU Stainless Steel fork light bariers in the V4A housing:













Feed control and fast trigger sensor in a sealing machine

Product OGU 050 G3-T3/V4A

Fork light barriers with V4A housing for feed control and as fast trigger sensors in pharmaceutical sealing machines

OGUP - OUR STRONG ONES.

FOR WHEN THINGS GET DIRTY.

LONG AFTER OTHER SENSORS HAVE GIVEN UP, THE OGUPS STILL HAVE PLENTY OF RESERVES LEFT.

Available with fork openings of 20, 30, 50 or 80 mm, the OGUP series ensures precise object detection regardless of the surface, even in dirty and oily production environments. With reproducibility of 0.03 mm, the fork light barriers offer a high degree of precision paired with maximum function reserve.


Additional benefits of the rugged OGUP infrared high-performance light barriers:

- Maximum function reserve while maintaining high switching accuracy
- Power sensor mode set by default; the Standard, High Resolution and Speed sensor modes can be freely selected
- Preferred field of application: mechanical engineering applications involving large amounts of dust, coolant or oil









Reliably functioning accumulation and position monitoring

OGUP 050 G3-T3

Fork light barriers of the OGUP series are equipped with infrared high-performance LEDs. This reduces cleaning cycles in a dirty environment to a minimum.

MAXIMUM PRECISION: OGUL LASERS. UNMATCHED RESOLUTION.

LASER FORK LIGHT BARRIERS ARE USED WHEN THE SMALLEST PARTS MUST BE DETECTED.

The OGUL series available with fork openings of 30, 50, 80 and 120 mm is the best solution when the goal is process-reliable and fast detection of very small objects down to a size of just 0.03 mm. With OGUL, the position and alignment of thin wires, drill bits or cannulae can effortlessly be defined down to a (reproducible) accuracy of 0.01 mm.



Additional benefits of the precise OGUL Lasers / OGUL Laser Stainless Steel:

- Fast, reliable detection of the smallest parts with a high functional reserve
- 4 pre-configured sensor modes: Standard mode is the default. The High Resolution, Speed and Power modes can be selected via IO link
- Preferred field of application:
 Detection of very small parts in assembly, handling and packaging technology, as well as quality control
- Robust, powder-coated metallic housing or cleanroom-compatible V4A stainless steel housing for areas with strict requirements for hygiene and resistance to cleaning agents – both in the high protection class IP67
- OGUL lasers work reliably and with high process safety in a temperature range between –25 °C and 60 °C





FOR DETECTION OF THE

SMALLEST FEATURES.

POSITION AND COMPLETENESS MONITORING IN PART FEEDING

Components must be checked for their position and completeness before they are fed to assembly machines. For this purpose, di-soric has a wide selection of product solutions that increase productivity, minimize machine downtimes and even prevent machine damage.



Position monitoring: groove present?

OGUL 051 G3-T3

The correct position of cylindrical components is verified by checking for the presence of a small groove. Our OGUL laser fork light barrier features a clearly visible laser beam and handles this task with functional reliability.

In the NC position of the potentiometer, the switching output is switched off if no groove is present, and the product can be rejected.

Cannulae monitoring

OGUL 031 G3-T3


A feeding unit transports disposable syringes in a hanging position to their final assembly station at a high speed. A rotary table is used to fit plastic caps on the syringes.

Before this table, the needles pass through a laser fork light barrier from the OGUL series. The thin needle has to be detected as present before the system is allowed to put the cap on.

The challenge in this application:

the cannula measures 0.3 mm, so the cycle times are short. Users in the clinical sector rely on the presence of a fully functional disposable syringe in every package.

On the left in the figure: an OGU 031 G3-T3/V4A for detecting the plastic caps.



COMPLETE SOLUTIONS USING IO-LINK:

TEAMWORK BY DI-SORIC.

SOLUTIONS, CLEVER, PRACTICAL.

IO-Link provides true added value over the entire service life of a system. The installation and commissioning of highly diverse sensors is simpler and faster whenever the use of plug connectors replaces full wiring. IO-Link products from di-soric allow for the creation of flexible, affordable, space-saving systems that will be available to the customer faster than ever. The advantages of an IO-Link are even more evident when it comes to parameter configuration and diagnostics. For the first time, system operators have an affordable standard that enables an unobstructed view and access to all interacting sensors at the process level.



SMART THANKS TO IO-LINK.

SAVE TIME AND MONEY.

EASY, FAST AND SAFE.

Field devices with an IO-Link interface feature on-board digital intelligence. This allows them to swap position, process, status and device information easily in a digital format. The sensor can be configured directly using the IO-Link master. Settings can be applied to the sensor directly via drag and drop by means of a control panel.

Even device replacement can be carried out quickly and easily with IO-Link and data storage in the master using the Smart Sensor Profile, without any expert knowledge.

5 REASONS TO CHOOSE OUR FORK LIGHT BARRIERS WITH IO-LINK.

- 1 Cost reduction thanks to reduced stockkeeping
 - One sensor can provide the solution for various applications by adjusting the configuration. Application-specific sensors are no longer necessary.
- 2 Implementation of innovative machine concepts thanks to consistent communication
 - Recipe management in the IO-Link master, remote maintenance, diagnostics, sensor-configuration in accordance with the standardized Smart Sensor Profile
- 3 Reduction of commissioning times through standard cabling and data storage in the master
 - Standard plug connectors and push/pull outputs
 - The sensor can be configured directly over the IO-Link master and is saved in the master with IO-Link 1.1
- 4 Increased machine productivity through configuration and identification
 - Additional functionality integrated directly into the sensor:
 Sensor modes, teach-in, evaluation of signal values, pulse extension, operation lock
- 5 Revolutionizing maintenance through self-diagnostics and data storage
 - Process stability diagnostics (e.g. function reserve)
 - Easy device swapping without manual intervention or specialized knowledge thanks to data storage in IO-Link 1.1 master



Configuration: Sensor mode Power - High function reserve

Increased transmitting power and thus increased function reserve with reduced sensitivity to dirt

Diagnostics: Qualitative process stability

Qualitative and quantitative diagnostics for the analysis of process stability and teach-in quality (qualitative), process values min / max, teach, switching point (quantitative)



TECHNICAL DATA OGU WITH IO-LINK

		SMAL	L ONES		MEDIU	IM FORMAT		
Fork ope	ening	5	10	20	30	40	50	60

	·	**************************************		66 (5) (2) (3) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4	ma (man) (2) 200-21 2 m = 2	66 (F)	00 01 00 01 00 0
Red light, 660 nm		No.	0GU 021 G3-T3	0GU 031 G3-T3	0GU 041 G3-T3	0GU 051 G3-T3	0GU 061 G3-T3
Infrared light, 880 nm	0GU 005 G3-T3	0GU 010 G3-T3	0GU 020 G3-T3	OGU 030 G3-T3		OGU 050 G3-T3	
Resolution (Smallest detectable part)	Ø 0.2 mm (min. Ø 0.1 mm) ¹	Ø 0.2 mm (min. Ø 0.1 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹
Reproducibility	0.02 mm	0.02 mm	0.02 mm	0.02 mm	0.02 mm	0.02 mm	0.02 mm
Adjustable switching frequency	10000 Hz (up to 14 000 Hz) ²	10000 Hz (up to 14 000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²
Housing dimensions H/W/D	25 / 45 / 10 mm	25 / 45 / 10 mm	40 / 50 / 10 mm	50 / 60 / 10 mm	60 / 70 / 10 mm	70 / 80 / 10 mm	80 / 80 / 10 mm
Housing material							
Zinc die-cast black powder-coated		•					
Aluminum black anodized	•						
Switching output	Push-pull/pnp/nj	pn adjustable via IO-	-Link, 100 mA, NO/N	NC (switchable via po	otentiometer or IO-Li	ink)	
Interface	10-Link V1.1	COM2 Smart Sei	nsor Profile				
Sensitivity adjustment	Using potention	meter or IO-Link					
Sensor modes	High Resolution Power – Increase	neral applications n – For detection of used function reserventection of fast-mover.	/e	ts			
Protection type /class	IP67 / III						
Connector	Plug, M8, 3-pin						
Connection cable	TK						
	Factory setting: §	Factory setting: Sensor mode Standard , ¹ in sensor mode High Resolution , ² in sensor mode Speed					





				LARGE			
70	80	90	100	120	170	220	250
							_
					Har (2 to 10	read to the state of the state	CAMES .
44 (4) (4) (4) (4) (4) (4) (4) (3 - 10 - 10 - 10 - 10 - 10 - 10 - 10 - 1	and 100 miles	700 (m. 170) 3 (m. 170) 3 (m. 170) 3 (m. 170)			
OGU 071 G3-T3	0GU 081 G3-T3	0GU 091 G3-T3	0GU 101 G3-T3	0GU 121 G3-T3	0GU 171 G3-T3	0GU 221 G3-T3	0GU 251 G3-T3
	OGU 080 G3-T3			0GU 120 G3-T3			
Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.5 mm (min. Ø 0.3 mm) ¹	Ø 0.5 mm (min. Ø 0.4 mm) ¹	Ø 1.0 mm (min. Ø 0.8 mm) ¹	Ø 1.0 mm (min. Ø 0.8 mm) ¹
0.02 mm	0.02 mm	0.02 mm	0.02 mm	0.02 mm	0.03 mm	0.03 mm	0.03 mm
5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 6500 Hz) ²	5000 Hz (max. 6500 Hz) ²
90 / 80 / 10 mm	100 / 80 / 10 mm	110 / 80 / 10 mm	120 / 80 / 10 mm	144 / 90 / 12 mm	194 / 140 / 12 mm	244 / 140 / 12 mm	274 / 140 / 12 mm
_	•		•	•	•	•	

TECHNICAL DATA

OGU STAINLESS STEEL WITH IO-LINK

	OGU STAINLESS STEEL							
Fork opening in mm	OGU STAIN	30	50	80	120			
	10	30	50	80	120			
					- G. E			
	- Terres	=01 a	14 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	A second	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			
	(CE*			-				
Red light, 660 nm		OGU 031 G3-T3/V4A	OGU 051 G3-T3/V4A	OGU 081 G3-T3/V4A	OGU 121 G3-T3/V4A			
Infrared light, 880 nm	OGU 010 G3-T3/V4A							
Resolution (smallest detectable part)	Ø 0.2 mm (min. Ø 0.1 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.3 mm (min. Ø 0.2 mm) ¹	Ø 0.5 mm (min. Ø 0.3 mm) ¹			
Reproducibility	0.02 mm	0.02 mm	0.02 mm	0.02 mm	0.02 mm			
Adjustable switching frequency	10000 Hz (up to 14000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²	5000 Hz (max. 8000 Hz) ²			
Housing dimensions H / W / D	25 / 45 / 10 MM	50 / 60 / 10 mm	70 / 80 / 10 mm	100 / 80 / 10 mm	144 / 90 / 12 mm			
Housing material								
Stainless steel V4A	•	•	•	•	•			
Zinc die-cast black powder-coated								
Switching output	Push-pull/pnp/npn adju	ustable via IO-Link, 100 mA	, NO/NC (switchable via pot	entiometer or IO-Link)	_			
Interface	IO-Link V1.1 COM2	I Smart Sensor Profile						
Sensitivity adjustment	Using potentiometer	or IO-Link						
Sensor modes	Standard – General ap High Resolution – For Power – Increased fun Speed – Safe detection	detection of the smallest onction reserve	objects					
Protection type /class	IP67 / III							
Connector	Plug, M8, 3-pin							
Connection cable	TK							
	Factory setting OGU V4	A: Sensor mode Standard,	¹ in the High Resolution se	ensor mode, ² in the Speed s	ensor mode			

OGUP WITH IO-LINK





OGUP			
20	30	50	80
			4-12-11 3-01 3-01
100 (M)	750 Mar 1 (2) (200 H) (2) (200 H) (2)	00 00 00 00 00 00 00 00 00 00 00 00 00	
:	:=	:	:=
OGUP 020 G3-T3	0GUP 030 G3-T3	0GUP 050 G3-T3	0GUP 080 G3-T3
Ø 2 mm (min. Ø 0.2 mm) ¹	Ø 2 mm (min. Ø 0.2 mm) ¹	Ø 2 mm (min. Ø 0.2 mm) ¹	Ø 2 mm (min. Ø 0.2 mm) ¹
0.03 mm	0.03 mm	0.03 mm	0.03 mm
200 Hz (max. 8000 Hz) ²	200 Hz (max. 8000 Hz) ²	200 Hz (max. 8000 Hz) ²	200 Hz (max. 8000 Hz) ²
40 / 50 / 10 mm	50 / 60 / 10 mm	70 / 80 / 10 mm	100 / 80 / 10 mm

TECHNICAL DATA

OGUL LASER WITH IO-LINK

	OGUL Laser					
Fork opening in mm	30	50	80	120		
		ration of the state of the stat				
Red light laser, class 1	0GUL 031 G3-T3	0GUL 051 G3-T3	0GUL 081 G3-T3	OGUL 121 G3-T3		
Resolution (Smallest detectable part)	Ø 0.05 mm (min. Ø 0.03 mm) ¹	Ø 0.05 mm (min. Ø 0.03 mm) ¹	Ø 0.05 mm (min. Ø 0.04 mm) ¹	Ø 0.1 mm (min. Ø 0.05 mm) ¹		
Reproducibility	0.01 mm	0.01 mm	0.01 mm	0.01 mm		
Adjustable switching frequency	5 000 Hz (max. 10 000 Hz) ²	5 000 Hz (max. 10 000 Hz) ²	5 000 Hz (max. 10 000 Hz) ²	5 000 Hz (max. 10 000 Hz) ²		
Housing dimensions H/W/D	50 / 60 / 10 mm	70 / 80 / 10 mm	100 / 80 / 10 mm	144 / 90 / 12 mm		
Housing material						
Stainless steel V4A						
Zinc die-cast black powder-coated	•	•	•	•		
Switching output	Push-pull/pnp/npn adjustable	via IO-Link, 100 mA, NO/NC (switch	chable via potentiometer or IO-Link	()		
Interface	IO-Link V1.1 COM2 Sm	art Sensor Profile				
Sensitivity adjustment	Using potentiometer or IO-	Link				
Sensor modes	Standard – General applicati High Resolution – For detec Power – Increased function r Speed – Safe detection of fas	tion of the smallest objects reserve				
Protection type /class	IP67 / III					
Connector	Plug, M8, 3-pin					
Connection cable	тк					
	Factory setting OGUL: Sensor	mode Standard , ¹ in the High Res	solution sensor mode, ² in the Spe	eed sensor mode		





OGUL Laser Stainl	ess Steel		
30	50	80	120
	•	11 N 11 N 1 N 1 N 1 N 1 N 1 N 1 N 1 N 1	To see
7. N 1 1 1 V	10 mg		
OGUL 031 G3-T3/V4A	0GUL 051 G3-T3/V4A	OGUL 081 G3-T3/V4A	OGUL 121 G3-T3/V4A
Ø 0.05 mm (min. Ø 0.03 mm) ¹	Ø 0.05 mm (min. Ø 0.03 mm) ¹	Ø 0.05 mm (min. Ø 0.03 mm) ¹	Ø 0.1 mm (min. Ø 0.05 mm) ¹
0.01 mm	0.01 mm	0.01 mm	0.01 mm
5 000 Hz (max. 10 000 Hz) ²	5 000 Hz (max. 10 000 Hz) ²	5 000 Hz (max. 10 000 Hz) ²	5 000 Hz (max. 10 000 Hz) ²
50 / 60 / 10 mm	70 / 80 / 10 mm	100 / 80 / 10 mm	144/90/12 mm
•	•	•	•

SOLUTIONS. CLEVER. PRACTICAL.

di-soric Headquarters

Germany: di-soric GmbH & Co. KG | Steinbeisstrasse 6 | 73660 Urbach Phone +49 71 81 98 79-0 | Fax +49 71 81 98 79-179 | info@di-soric.com

di-soric Subsidiaries

Austria: di-soric GmbH & Co. KG | Phone +43 7228 72 366 | info.at@di-soric.com

China: di-soric Industrial Automation (Suzhou) Co. Ltd. | Phone +86 512 6260 9518 | info@di-soric.cn

France: di-soric SAS | Phone +33 476 61 65 90 | info.fr@di-soric.com
Singapore: di-soric Pte. Ltd. | Phone +65 6694 7866 | info.sg@di-soric.com
The Netherlands: di-soric B. V. | Phone +31 413 33 13 91 | info.nl@di-soric.com

For further information visit www.di-soric.com/international